

Fig. 7)		
>TRIGGER SETUP	2 CHANNEL GRAPH	3 CHANNEL GRAPH	Y SELECTS, N EXITS GRAPHICS MODE.

MODE.

>ENABLE TRIGGER	DISABLE TRIGGER	DIT TRIGGER	SELECTS, N EXITS GRAPHICS MODE.
>ENAB	DISA	EDIT	Y SEL

>A/C RELAY
SCROLL TO SELECT PARAMETER.
Y SELECTS, N EXITS GRAPHICS MODE.

Fig. 9

Fig. 10

A/C RELAY	.AY
>GREATER	THAN
SCROLL TO	O SELECT TRIGGER THRESHOLD.
Y SELECTS,	'S, N EXITS GRAPHICS MODE.

<u> </u>			
A/C RELAY	EQUAL TO	NO<	Y SELECTS, N EXITS GRAPHICS MODE.
	L	L	Ь

Fig. 12


Y SELECTS, N EXITS GRAPHICS MODE. >0123456789.- DELETE DONE BACK BATTERY (V) LESS THAN


BACK Y SELECTS, N EXITS GRAPHICS MODE. >TRIGGER @ LEFT CENTER RIGHT 11.75 BATTERY (V) LESS THAN

Fig. 13

Fig. 14

>ACCEPT
BATTERY(V)
LESS THAN 11.75 @ CENTER
Y SELECTS, N EXITS GRAPHICS MODE.








Fig. 18




Fig. 17




Fig. 19

